


AIRI 22 plastic






Assembly instruction

1/21

Important !
Wichtig !





Important !
Wichtig !



AIRI 22 plastic

Assembly instruction



| | | | | | | |
|-----------|---|-----------|---|-----------|---|-----------|
| 1b | + | 1a | + | 1b | + | 2a |
| + | | 1a | + | 2b | + | 1a |

fixing

| | | |
|-----------|---|-----------|
| 1a | + | 1b |
|-----------|---|-----------|

| | |
|-----------|----------|
| 68 | 4,5 x 80 |
|-----------|----------|

fixing




| | | |
|-----------|-----------|-----------|
| 2a | 2b | 2c |
|-----------|-----------|-----------|

| | |
|-----------|--------|
| 96 | 4 x 60 |
|-----------|--------|

AIRI 22 plastic

Assembly instruction

3/21



1b

3a

+

3b



+

3c

AIRI 22 plastic

Assembly instruction



4/21



AIRI 22 plastic

Assembly instruction

5/21




| | | | | |
|----|----|----|--------|----------|
| 5b | + | 4a | | |
| | + | 4b | + | |
| 4b | + | 4c | | |
| | + | 4c | + | |
| 4a | + | 5a | 28 | 4,5 x 80 |
| 5b | 4a | 4b | | |
| 4b | 4c | 4c | | |
| 4a | 5a | + | bottom | 16 |
| | | | | 4,5 x 80 |

AIRI 22 plastic

Assembly instruction

6/21




| | | | | | | | | |
|-----------|---|-----------|---|-----------|---|-----------|-----------|-----------------|
| 5c | + | 5a | + | 5d | + | 5b | | |
| | + | 4d | + | 4b | + | 4b | 28 | 4,5 x 80 |
| 5c | | 5a | | 5d | | 5b | | |
| 4b | | 4b | | + | | bottom | 14 | 4,5 x 80 |

AIRI 22 plastic


Assembly instruction

7/21



+ **6**

| | |
|---|----------|
| 4 | 4,5 x 80 |
|---|----------|




+ **7d**

| | |
|----|----------|
| 12 | 4,5 x 80 |
|----|----------|


AIRI 22 plastic

Assembly instruction

8/21





| | | | | | | |
|-----------|---|-----------|---|-----------|-----------|-----------------|
| 7a | + | 7b | + | 7c | 26 | 4,5 x 80 |
|-----------|---|-----------|---|-----------|-----------|-----------------|






| | | | | |
|--------------------------|---|-----------|-----------|-----------------|
| | + | 7d | 14 | 4,5 x 80 |
| end of the panels | + | 7d | 14 | 3,5 x 50 |

AIRI 22 plastic

Assembly instruction



| | | | | | | |
|------------|---|------------|---|------------|-----------|-----------------|
| 12a | + | 12b | + | 12c | 52 | 3,5 x 40 |
|------------|---|------------|---|------------|-----------|-----------------|



to the upper belt with angle

+ **8** ...

| | |
|-----------|-----------------|
| 30 | 4,5 x 80 |
|-----------|-----------------|

to the upper belt with angle

+ **9a** **9b** ...

| | |
|-----------|-----------------|
| 30 | 4,5 x 80 |
|-----------|-----------------|



8

+

9a

+ ...




between

| | |
|-----------|---------------|
| 80 | 4 x 60 |
|-----------|---------------|

AIRI 22 plastic

Assembly instruction

10/21



to the rafter with angle or through

+ middle supports

+

11



+ middle supports

| | |
|----|----------|
| 20 | 4,5 x 80 |
| 8 | 40x40x40 |
| 48 | 3,5 x 40 |

AIRI 22 plastic

Assembly instruction



11/21



AIRI 22 plastic

Assembly instruction

12/21





| | | |
|-------|---|------------|
| front | + | 14a |
| side | + | 14b |
| back | + | 14a |

| | |
|-----|----------|
| 168 | 3,5 x 40 |
| 48 | 3,5 x 40 |
| 48 | 3,5 x 40 |


AIRI 22 plastic

Assembly instruction

13/21



| | | | | | | |
|-----|---|-----|---|-----|-----|----------|
| 13a | + | 13b | + | 13c | 160 | 3,5 x 40 |
|-----|---|-----|---|-----|-----|----------|




| | | | | | | |
|-----|---|-----|---|----|----|----------|
| 15a | + | 15b | + | 16 | 24 | 3,5 x 40 |
|-----|---|-----|---|----|----|----------|

AIRI 22 plastic

Assembly instruction



14/21



AIRI 22 plastic

Assembly instruction

15/21





| | | | | | | |
|-----|---|-----|---|-----|----|----------|
| 17a | + | 17b | + | 18 | | |
| | + | 19a | + | 19b | 40 | 3,5 x 40 |



AIRI 22 plastic

Assembly instruction

16/21





| | | | | |
|----|---|----|----|----------|
| 20 | + | 21 | 64 | 3,5 x 40 |
|----|---|----|----|----------|

AIRI 22 plastic

Assembly instruction


17/21





| | | | | | | |
|----|---|-----|---|-----|----|----------|
| 22 | + | 23 | + | 24a | | |
| | + | 24b | + | 24c | 88 | 3,5 x 40 |

AIRI 22 plastic


Assembly instruction



NB! 32 + 31 + 30
33 + 34 + 35 + 36




NB! 42 + 41 + 40 + 43



AIRI 22 plastic



Assembly instruction

19/21




NB!

| | | | | |
|----|---|----|---|----|
| 52 | + | 55 | + | 54 |
| 53 | + | 51 | + | 50 |



NB!


| | | | | |
|----|---|----|---|----|
| 62 | + | 61 | + | 60 |
|----|---|----|---|----|



AIRI 22 plastic

Assembly instruction


20/21



+ **73** **88** 3,5 x 40





70 + **71** + **72**



44 **45** **46** **47** interior paneling corner slats

8 pcs. 8 pcs. 8 pcs. 4 pcs.






AIRI 22 plastic

Assembly instruction

21/21

90
8 pcs.



Spare screw set:

| | | |
|--------|----------|----------|
| 4 x 60 | 3,5 x 50 | 3,5 x 40 |
| 6 pcs. | 6 pcs. | 8 pcs. |